
802-004 1/24 **FIG. 1A**



454 802-004

FIG. 1B








FIG. 2




802-004 4/24


FIG. 3




802-004 5/24 FIG. 4




802-004 6/24 FIG. 5







802-004

FIG. 7









802-004 11/24

FIG. 10










FIG. 13



-1G. 14



802-004

802-004

FIG. 15






FIG. 16


807-004



802-004 17/24




F16.18




802-004


F16.19




20/24

F16.20







```
Fig. 23
                           <?xml version="1.0" encoding="UTF-8" ?>
                       - <formats>
                               msq id="128" name= UPDATE_START_CMD">
                                    <desc>Start PNUT update</desc>
                                   <byte name="type" transient="true" />
                                    <bytes name="checksum" size="2" />
 496
                               Smsg id="129" name="UPDATE_MSG_CMD"> 504
                                    desc>PNUT data update packet / desc>
                                   <br/>
<br/>
bytes name="packet number" size="2"/>
                                    <bytes name="length" size="2" transient="true" />
                                   <br/>

 502
                                        max_print="0" />
                                                                                                                                                                              508
                               </msg>
                           - <msg id="130" name="UPDATE_LAST_MSG_CMD">
                                   <desc>Last PNUT update packet</desc>
                                     bytes name="packet number"|size="2" transient="true" />
                                   <pad size="8" />
                                                                                                                                                                  510
                               </msg>
                           - <msg id="132" name="UPDATE_CNX_CMD">
                                   <desc>Cancel PNUT update</desc>
                                   <pad size="24" />
                               </msq>
                           - <msg id="136" name=|UPDATE_COMP_CMD"|>
                                   <desc>PNUT update complete</desc>
                                 <bytes name="status" size="1" transient="true">
                                           status success + "0">
514
                                             <desc val=10">Successful</desc>
                                            <desc val="1">Bad packet checksum</desc>
                                             <desc val= 2 >Flash write failure / desc
      518
                                            <desc val="3">Update cancelled</desc>
                                        </status>
                                   </bytes>
                                                                                                               520
                                   <pad size="16" />
                               </msq>
                          </formats>
```

